




Congratulations, and thank you for choosing SuperPonics. You now have the world's finest hydroponic system.

These instructions will guide you through the process of setting up your SuperCloner 50. Please read through the entire instruction manual before you begin, including any and all instructions that come with the individual components.



COMPONENTS



UNPACKING THE SYSTEM

Carefully unbox your SuperPonics[®] system. Remove all contents from inside the Reservoir as well.


2

1


Prior to setup, make sure you have all of the necessary components by cross referencing with the QAC (Quality Assurance Checklist). Take this time to familiarize yourself with each of the components.



SET UP




Remove the lid from the SuperCloner 50 system and set it aside for now. Notice the channels located on the rim of the Reservoir. These channels will be for the placement of your Air Pump Tubing.




Locate the two blue Air Stones included in your shipment. Place the Air Stones at the bottom of the SuperPonics[®] Reservoir.

NOTE: The Air Stones have a male end that will fit in the black Air Pump Tubing.



Connect the Air Pump Tubing to the end of the Air Stones. Arrange the tubing into the channels located on rim of the Reservoir.

SET UP



SUPER GROW TIP

Your plant roots need and love oxygen! It is extremely important to the health of the plants that you keep your Air Pump and Air Stones running at all times when the system is in use.

SET UP



Place the lid on your SuperCloner 50 and insert the Net Cups. See the below graphic for tips on growing medium and water levels.

