

Setting your Timers

1. Locate the Single Timers that are included in your system (image a). On the outer rings of the timer dial, you will notice small plastic tabs (image b). Each tab represents 15 minutes. Clicking down four tabs in a row would equal one hour.

3. Set the current time:

- 1) Rotate the numbered dial until the selection arrow points to the current time of day (image c) Note: Shaded selection represents nighttime hours.
- 2) Set ON time: Click down the tabs for each hour you would like the timer to be ON.
- 3) Set Timer to RUN: Use the switch on the side or top of the timer to make sure the timer is in **TIMER MODE**. By toggling this switch to the **ALWAYS ON** position, the timer will be bypassed and the device plugged into that timer will be ON at all times.



4. Recommended Timer Settings:

1) Water Pump

The Water Pump is recommended to run for 15 minutes (one tab) every 6 hours - Or 4 times per day. This can be adjusted to give the plants more or less water depending on their overall health (image d).




2) Light - Vegetation Stage

During the Vegetation Stage, you want the timer to run for 18 hours ON and 6 hours OFF. Press down every tab for a total of 18 hours (3/4 of the entire dial) starting with the time when you want your light to turn ON.

3) Light - Flowering Stage

During the Flowering Stage, you want the timer to run for 12 hours ON and 12 hours OFF. Press down every tab for a total of 12 hours (1/2 of the entire dial) starting with the time when you want your light to turn ON.

**Light setting may vary from plant to plant.*



VEGETATION

FLOWER

